




INPUT CONTROL
 THREE WIRES FROM no. 4444 TOUCH SWITCH.
 IF CONTACT TYPE SWITCH IS USED, CONNECT SWITCH ACROSS WHT & BLK TERMINALS.
 IF MORE THAN ONE INPUT SWITCH IS USED FOR CONTROL, CONNECT SWITCHES IN PARALLEL.
 IF TWO 4300 UNITS ARE TO BE OPERATED SIMULTANEOUSLY, CONNECT INPUT CONTROLS IN PARALLEL.

CIRCUIT BOARD CONNECTIONS AND ADJUSTMENTS



	POWER ACCESS CORPORATION
	ELECTRICAL DETAILS
	MODEL 4300
3/94	4265D