


HOW TO MEASURE (4) HINGE PLACEMENTS AND DOOR SIZE



MEASURE HINGES AS FOLLOWS:
TOP OF DOOR TO TOP OF 1ST HINGE,
TOP OF 1ST HINGE TO TOP OF 2ND HINGE,
TOP OF 2ND HINGE TO TOP OF 3RD HINGE,
TOP OF 3RD HINGE TO TOP OF 4TH HINGE,

**RIGHT HAND SHOWN,
 LEFT HAND OPPOSITE**

NOTE: MEASURE DOOR FROM HALL SIDE